


NWL-O CORE BARREL



KUVAWALA 'O' WIRELINE CORE BARRELS WITH LANDING INDICATOR.

	ITEM DESCRIPTION	PART NUMBERS
1-39	NWL-O CORE BARREL 3.0m / 10 ft	16-00-100
1-39	NWL-O CORE BARREL 1.5m / 5 ft	16-00-110
1-33	NWL-O INNER TUBE ASSEMBLY 3.0m / 10ft	16-00-120
1-33	NWL-O INNER TUBE ASSEMBLY 1.5m / 5ft	16-00-130
1-29	NWL-O HEAD ASSEMBLY	16-00-140
1	SPEARHEAD POINT	16-01-001C
2	KNUCKLE HEAD COMPRESSION SPRING	16-01-004
3	DETENT PLUNGER	16-01-003
4	NWL POINT BODY	16-01-002
5	SOLID PIN 7/16" x 1 1/8"	16-01-005
6	NWL-O CASE LATCH	16-01-046
7	NWL SPRING DOWELL 1/2" x 2" - 2 NOS.	16-01-011
8	NWL LATCH SPRING	16-03-009
9	NWL LATCH - 2 NOS.	16-03-008
10	NWL SOLID PIN 1/2" x 1 1/2"	16-01-010
11	NWL-LL UPPER BODY LATCH	16-05-007
12	NWL-LL LANDING SHOULDER	16-05-014
13	NWL-LL LOWER BODY LATCH	16-05-013
14	NWL-LL SPRING WASHER	16-05-035
17	NWL HEX NUT	16-01-013
18	NWL ADJ SPINDLE ASSEMBLY	16-01-012
19	NWL SHUT OFF VALVE - 2 NOS.	16-01-014
20	NWL VALVE ADJ WASHER - 2 NOS.	16-01-015
21	NWL THRUST BEARING	16-01-017
22	NWL BEARING COVER	16-01-020
23	NWL BEARING SPINDLE	16-01-018
24	GREASE FITTING	16-01-019
25	NWL HANGER BEARING	16-01-016
26	NWL COMPRESSION SPRING	16-01-021
27	NWL NYLOCK NUT, 3/4" UNC	16-01-022
28	NWL-LL INNER TUBE CAP ASSEMBLY	16-05-018
28A	NWL-LL INNER TUBE CAP VALVE BODY	16-05-019
29	STAINLESS STEEL BALL 22 mm	16-03-014
30	NWL INNER TUBE 1.5m / 5 ft	16-01-025
30	NWL INNER TUBE 3.0m / 10 ft	16-01-024
31	NWL RING STOP	16-01-026
32	NWL CORE LIFTER (FLUTTED)	16-01-027A
32	NWL CORE LIFTER (SLOTTED)	16-01-027B
33	NWL CORE LIFTER CASE	16-01-028
34	NWL LOCKING COUPLING (HF)	16-01-029
35	NWL ADAPTER COUPLING	16-01-030
36	NWL RING LANDING	16-01-031
37	NWL OUTER TUBE 1.5m / 5 ft	16-01-033
37	NWL OUTER TUBE 3.0m / 10 ft	16-01-032
38	NWL STABILIZER RING	16-01-034
39	NWL CB THREAD PROTECTOR	16-01-035
40	LANDING INDICATOR BUSH	16-05-015
41	STAINLESS STEEL BALL 22 mm	16-05-017